

How To Install Privacy Picket Panels

Our privacy slats can be used for either 100% privacy, or turn them 90° to guide air into your fenced area. Installing these privacy slats is a snap, literally!

Required Tools: To cut and install your panels, you will need a miter saw or band saw, a drill with a 1/4" drill bit, and a rubber mallet.

Step 1: Cut the panels, and optional extender clips and locks

Measure the length of your pickets from the bottom of your channel to the top of your bottom channel. This will give you a dimension to start cutting your pickets. We recommend cutting 1/4" shorter than your measurement. This will allow for expansion.

Step 2: Snap the panels onto the fence

Pry open the top of the privacy panel with your fingers. Line it up with the fence picket and snap on. Use the rubber mallet to tap the panel into place, making sure it's secure all the way down.

If you are using extender clips Step 3: Drill and secure with clips and buttons

Take an extender clip, start from the top and slide down the privacy panel. This will line right up and lock in place. Take your drill and drill a hole on the center line of the extender clip. You can use as few or as many buttons as needed to secure the extender clip to the privacy panel.

Normally, you will need about 3 or 4 buttons for 4' and 5' panels, and more for taller panels. Take the button, line it up with the hole, and push hard to lock it. It will make a snapping sound.

